

SAFETY AND USAGE INSTRUCTIONS

Read the safety instructions before use and follow them.

The lift should only be used by a person over 18 years of age who is familiar with these SAFETY INSTRUCTIONS AND LIFTING GUIDELINES and understands them.

SAFETY GUIDELINES FOR USE

- 1. Use the lift only for its intended purpose, which is lifting a car.**
- 2. Do not overload the lift. The maximum load is 3500 kg.**
- 3. Keep the lift and the work area clean and free from tools, parts, debris, etc.**
- 4. Keep the work area dry and also dry it regularly during work.**
- 5. Closely monitor the vehicle and the lift during lifting and lowering.**
- 6. Do not allow anyone to remain in the work area during lifting and lowering.**
- 7. Ensure that the vehicle's doors are closed during lifting and lowering.**
- 8. Do not allow anyone to climb on the lift.**
- 9. Secure the vehicle against unintended movement (handbrake, chocks).**
- 10. Do not run the vehicle's engine while on the lift; the ventilation in the area is not sufficient.**
- 11. Removing heavy components from the vehicle may quickly alter the vehicle's center of gravity on the lift.**

Plan the work carefully AND AVOID IT IF YOU ARE NOT SURE ABOUT ITS SAFETY!